


Load Cell cables available in lengths from 1 to 500 feet

HRT-181 TENSIO METER
Available for the following rope sizes; -1/2", -3/4", -5/8", -7/8", 9/16", -1"

8-Way Cables available in lengths from 2 foot to 600 feet

LOAD CELL CABLE
PN A048010-xx

A2B SHORTING PLUG
PN S035020



LOAD CELL DOG BONE
30K CELL -PN A235200-030K
50K CELL -PN A235200-050K

Use adapter plate including pins when using 30K load cell, PN A235999

SWING ARM AND MOUNTING BRACKET PLUS LANDING PAD
PN A240174

HRT 181 TENSIO METER
PN A230000-xx

CABLE ASSEMBLY 8 WAY STORAGE REEL TO J-BOX
PN A048050-xx

JUNCTION BOX
PN A260003



Greer LALT-1151L System

STORAGE REEL
PN A240105


CABLE ASSEMBLY 8 WAY METER TO STORAGE REEL
PN A048050-xx

ANGLE SENSOR
PN A220220

CABLE ASSEMBLY, ANGLE SENSOR TO METER 30 FEET
PN A047037


LALT-1151L METER
PN A310107

HRT 179 TENSIO METER
FOR ROPE SIZES ABOVE 1
PN A230010-xx



HRT-179 TENSIO METER
Available for the following rope sizes; -1 1/8", 1 1/4"

HRT 186 TENSIO METER
LOW PROFILE
PN A230020-xx



HRT-186 TENSIO METER
Available for the following rope sizes; -1/2", -9/16", -5/8, 3/4"

LALT-1151L LATTICE TIP-MOUNT NO A2B

