

**A2B Cables available in lengths from 1 to 500 feet**

**Load Cell cables available in lengths from 1 to 500 feet**

SWING ARM AND MOUNTING BRACKET PLUS LANDING PAD  
PN A240174

HRT 181 TENSIO METER  
PN A230000-xx

**HRT-181 TENSIO METER Available for the following rope sizes; -1/2", -3/4", -5/8", -7/8", 9/16", -1"**

**8-Way Cables available in lengths from 2 foot to 600 feet**

LOAD CELL CABLE  
PN A048010-xx

A2B CABLE  
PN A048000-xx

CABLE ASSEMBLY 8 WAY STORAGE REEL TO J-BOX  
PN A048050-xx

STORAGE REEL  
PN A240105

CABLE ASSEMBLY 8 WAY METER TO STORAGE REEL  
PN A048050-xx

JIB A2B SWITCH  
PN A250015

JUNCTION BOX  
PN A260003

ANGLE SENSOR  
PN A220220

CABLE ASSEMBLY, ANGLE SENSOR TO METER 30 FEET  
PN A047037

MAIN A2B SWITCH WITH SELECTOR  
PN A250003

A2B CHAIN & WEIGHT  
PN A251005

LALT-1151L METER  
PN A310107



### Greer LALT-1151L System

**Optional A2B Switch for Auxiliary Head (5' lead) PN A250023**


LOAD CELL DOG BONE  
30K CELL -PN A235200-030K  
50K CELL -PN A235200-050K

**Use adapter plate including pins when using 30K load cell, PN A235999**


HRT 179 TENSIO METER  
FOR ROPE SIZES ABOVE 1  
PN A230010-xx

HRT 186 TENSIO METER  
LOW PROFILE  
PN A230020-xx

# LALT-1151L LATTICE TIP-MOUNT INCLUDING A2B



**HRT-179 TENSIO METER Available for the following rope sizes; -1 1/8", 1 1/4"**



**HRT-186 TENSIO METER Available for the following rope sizes; -1/2", -9/16", -5/8, 3/4"**

