

- K. The hoist hydraulic motor and brake valve are supplied only by LANTEC.
- L. The hoist must NOT be used for Personnel Handling if the hoist experiences any incident of failure to hold a load or exhibits improper or suspect operating characteristics.
- M. Hoist must NOT be used for Personnel Handling if it is known to have experienced an overload condition.
- N. Hoist unit is factory labelled with a nameplate which states "Approved for Personnel Handling on an API Spec 2C Crane".

**Failure to comply with ALL the above conditions
renders the hoist as NOT rated for Personnel Handling.**

**Promptly report any occurrence of hoist failure while
handling personnel to the General Manager at LANTEC.**

End of Bulletin

LANTEC

a division of IMAC Design Group Ltd

5827 Production Way

Langley, BC, Canada V3A 4N5

Tel (604) 530-0737 - Fax (604) 530-2889

email: lantec@lantecgear.com - web site: www.lantecgear.com

